

Dual Channel

THERMOMETER

Model : TM-914C/F

ISO-9001, CE, IEC1010



TM-914C (-40 to 1,200 °C)

TM-914C (-40 to 2,000 °F)



Type K probe (optional _

TP-01, TP-02A, TP-03, TP-04



Lutron

LUTRON ELECTRONIC

The Art of Measurement

DUAL CHANNEL THERMOMETER, °C model : TM-914C

DUAL CHANNEL THERMOMETER, °F model : TM-914F

FEATURES	
* Pocket size & compact housing.	* Build in precision cold junction compensation circuit.
* Dual channel input.	
* LCD display allows clear read-out even at high ambient light environment.	* Thermocouple sensor for Temperature measurement, fast response time.
* Operates from DC 9V battery.	* Used the durable, long-lasting components, including a strong, light weight ABS-plastic housing case.
* Low power consumption.	* Full line, wide range optional thermocouple probe.
* Meet any standard type K (NiCr-NiAl) probe.	* Optional holster.
* Fitted with standard type K input measuring socket.	

SPECIFICATIONS			
Display	3 1/2 digits with annunciator, 15 mm (0.5") LCD.	Sampling Time	Approx. 0.4 second.
Sensor Type	Thermocouple K (NiCr-NiAl), Optional.	Power Supply	DC 9 V battery, 006P, MN1604 or equivalent.
Measurement	Two channel input (T1, T2).	Power Current	Approx. DC 1.8 mA.
Range	<i>TM-914C</i> : -40 °C to 1200 °C x 1 °C .	Dimension	108 x 73 x 23 mm (4.3 x 2.9 x 1.4 inch).
Resolution	<i>TM-914F</i> : -40 °F to 1382 °F x 1 °F .	Weight	140 g/0.31 LB.
		Accessory	Operation Manual.... 1 PC.

ACCURACY (23± 5 °C)	
<i>TM-914C</i> :	<i>TM-914F</i> :
0 to 750°C : ± (1 % + 1 °C)	32 to 1382°F : ± (1 % + 2 °F)
750 to 1000°C : typ. - ± (2 % + 1 °C)	1382 to 1832°F : typ. - ± (2 % + 2 °F)
1000 to 1200°C : typ. - ± (4 % + 3 °C)	1832 to 2000°F : typ. - ± (2 % + 4 °F)
0 to -20°C : typ. ± 2 °C	32 to -4°F : typ. ± 4 °F
-20 to -40°C : typ. ± 3 °C	-4 to -40°F : typ. ± 6 °F
* typ. : Typically	* typ. : Typically

OPTIONAL TEMPERATURE PROBE & OTHER ACCESSORIES		
Temperature Probe	Model : TP-01	-40 °C to 250 °C continuous (300°C short-term). Applications : Ultra fast response naked-bead thermocouple wire, suitable for many general purpose application.
	Model : TP-02A	-50 °C to 900 °C (-50 °F to 1650 °F). Dimension : 10 cm tube, 3.2 mm Dia. Penetration & Immersion applications.
	Model : TP-03	-50 °C to 1200 °C (-50 °F to 2200 °F). Dimension : 10 cm tube, 8 mm Dia. Applications : High temperature, Penetration & Immersion.
	Model : TP-04A	-50 °C to 400 °C (-50 °F to 752 °F). Dimension : Temp. sensing head-15 mm Dia. Probe length-120 mm. Applications : Precision surface temp. measurement usage.
Carrying case	Model : CA-04	Soft carrying case.
Holster	Model : HS-02	High quality rubber protective holster.

* Appearance and specifications listed in this brochure are subject to change without notice.

0505-TM914